

## MANUAL FOR HANGING THE PHOTO MURALS

### Tools

- 1) Glue
- 2) Brush
- 3) Roller
- 4) Bucket
- 5) Cutter or knife
- 6) Spirit level
- 7) Pencil, ruler, measuring jug

### Surface preparation

At first, eliminate all rough areas and fill all holes and cracks. The surface must be free of grease, clean and smooth. We don't recommend hanging the photo mural on plaster walls. If the surface is porous, please apply a primer/mist coat or prelate before papering in order to prevent it from absorbing glue. In case of painted walls, clean them and use the grinding paper for better application of glue.

### Preparation for hanging

Before the very hanging of the photo murals, make sure that the panels have no defects or damages, that they have the right size and colours, and that they fit into each other. All instructions for preparation of glue are written in the manual of the producer. Some of our photomurals have the white security edge, which must be cut before installation.

### Hanging

Use a spirit level and draw guidelines. Cover the whole unprinted area evenly with paste by brush or roller and wait max. three minutes till the material soaks up. **Be careful! You must soak up every panel for exactly the same time.** You must pay attention in order to not bend the edges. It is vital that the first panel is hung straight. After that, smooth down the photo mural from the middle and smoothing out towards the edges. Any small bubbles and folds will disappear once the wall mural has dried. Paste the panels with overlap of 2 – 3 mm. It is really important to keep this way of pasting, otherwise there could appear inaccuracy among single panels. The room temperature shouldn't be higher than 20°C.

### Removing the photo mural

If you decide to remove the photo mural, use special tools for removing the wallpapers. Afterwards moisturize the photo mural with a brush or a sponge. After 15 minutes, remove the photo mural with spatula from the top down.